




© Copyright 2000. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746



8-Port Serial Host Adapter PCI



**CUSTOMER
SUPPORT
INFORMATION**

Order toll-free in the U.S. 24 hours, 7 A.M. Monday to midnight Friday: 877-877-BBOX
FREE technical support, 24 hours a day, 7 days a week: Call 724-746-5500 or fax 724-746-0746
Mail order: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

**FEDERAL COMMUNICATIONS COMMISSION
AND
INDUSTRY CANADA
RADIO FREQUENCY INTERFERENCE STATEMENTS**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par Industrie Canada.

This product is  approved.

NORMAS OFICIALES MEXICANAS (NOM) ELECTRICAL SAFETY STATEMENT

INSTRUCCIONES DE SEGURIDAD

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.
4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc..
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico deber ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.
11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.

12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equipo eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.
16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

TRADEMARKS

The trademarks mentioned in this manual are the sole property of their owners.

CONTENTS

1. Specifications 6

2. Introduction 7

 2.1 Overview 7

 2.2 What’s Included 7

3. Card Setup. 8

 3.1 Clock Modes 8

 3.2 Baud Rates and Divisors for the “Div1” mode 9

 3.3 Address and IRQ selection 10

4. Installation 11

 4.1 Setting Up the Operating System 11

 4.1.1 Windows 3.1x 11

 4.1.2 Windows 95/98 11

 4.1.3 Windows NT 11

 4.1.4 DOS 11

 4.1.5 Other Operating Systems 11

 4.2 Installing the Hardware 12

5. Technical Description 13

 5.1 Interrupts 13

 5.2 Why Use an ISP? 13

6. Connector Pin Assignments. 14

 6.1 DB25 (RS-232 DTE) 14

 6.2 DB78 Connector Pin Assignments 14

Appendix A: Troubleshooting. 15

 A.1 Using the Serial Utility Diskettes 15

 A.2 Calling for Technical Support. 15

Appendix B : Electrical Interface (RS-232) 16

Appendix C: Asynchronous Communications 17

Appendix D: Board Layout 10

Appendix E: Compliance Notices 20

 E.1 Federal Communications Commission Statement (see page 1) .. 20

 E.2 EMC Directive Statement. 20

1. Specifications

Communications Chip — IC142C: 16554 UART; IC190C: 16950 UART

Maximum Distance — 50 ft. (15.2 m)

Operation — RS-232

Protocol — Asynchronous

Speed — IC142C: Up to 460.8 kbps;
IC190C: 460.8 kbps and above

CE Approval — Yes

Temperature — Operating: 32 to 122 °F (0 to 50 °C);
Storage: -4 to 158 °F (-20 to 70 °C)

Humidity — 10 to 90% noncondensing

Connectors — (1) DB78 female on card, (1) DB78 male and (8) DB25 male on included octopus cable

Cable Length — 36" (91.4 cm)

Power — From the interface: +5 V @ 250 mA; +12 V @ 60 mA; -12 V @ 100 mA

Size — Half-card

2. Introduction

2.1 Overview

The 8-Port Serial Host Adapter PCI provides the PC with eight RS-232 asynchronous ports. The Adapter allows for connection to any device using the RS-232 electrical interface, such as modems, data-entry terminals, and plotters.

2.2 What's Included

The Serial Host Adapter PCI is shipped with the following items:

- 8-Port Serial Host Adapter PCI
- DB78 to eight DB25 Octopus Cable
- (2) Serial Utility Software Diskettes
- User Manual

If any of these items is missing or damaged, contact Black Box immediately at 724-746-5500.

3. Card Setup

3.1 Clock Modes

The Adapter employs a unique clocking option that allows the end user to select from divide-by-4 and divide-by-1 clocking modes. This mode is selected at J1.

To select the baud rates commonly associated with COM ports (2400, 4800, 9600, 19.2, ... 115.2 kbps), place the jumper in the divide-by-4 position (marked DIV4).




Figure 3-1. Clocking Mode “Divide By 4.”

To select the maximum data rate (460.8 kbps), place the jumper in the divide-by-1 position (marked DIV1).




Figure 3-2. Clocking Mode “Divide By 1.”

3.2 Baud Rates and Divisors for the “Div1” mode

The following table shows some common data rates and the rates you should choose to match them if using the adapter in the “Div1” mode.

Table 3-1. Baud Rates for the “Div1” Mode.

For this Data Rate	Choose this Data Rate
1200 bps	300 bps
2400 bps	600 bps
4800 bps	1200 bps
9600 bps	2400 bps
19.2 kbps	4800 bps
57.6 kbps	14.4 kbps
115.2 kbps	28.8 kbps
230.4 kbps	57.6 kbps
460.8 kbps	115.2 kbps

If your communications package allows the use of baud-rate divisors, choose the appropriate divisor from the following table:

Table 3-2. Baud-Rate Divisors for the “Div1” Mode.

For this Data Rate	Choose this Divisor
1200 bps	384
2400 bps	192
4800 bps	96
9600 bps	48
19.2 kbps	24
38.4 kbps	12
57.6 kbps	8
115.2 kbps	4
230.4 kbps	2
460.8 kbps	1

3.3 Address and IRQ selection

The Adapter is automatically assigned I/O addresses and IRQs by your motherboard BIOS. Only the I/O address may be modified by the user.

Adding or removing other hardware may change the assignment of I/O addresses and IRQs.

4. Installation

IMPORTANT

You **MUST** set up the operating system **BEFORE** you physically install the Card.

4.1 Setting Up the Operating System

If you are installing the PCI adapter in DOS, OS/2®, or QNX, please refer to the appropriate directory on one of the Serial Utilities Disks for instructions.

4.1.1 WINDOWS 3.1x

Refer to the Win3x.hlp file in the \Win31 directory on Disk 1 of the Serial Utilities software.

4.1.2 WINDOWS 95/98 USERS

If you are installing the PCI card in Windows 95/98, run setup on disk two of the Serial Utilities Diskettes before installing the card. Power down the computer and install the adapter. The resources are automatically configured for the PCI card. Refer to the appropriate help file in the Black Box folder located in the **Start, Programs** menu for changing those resources.

4.1.3 WINDOWS NT

If you are installing a PCI card in Windows NT, run setup on disk two of the Serial Utilities Diskettes before installing the card. After the software installation is complete, power down the computer, install the card, then power up. Since resource allocation is automatic, the installation is now complete.

4.1.4 DOS

Refer to the Readme.txt file found in the \DOS directory on Disk 1 of the Serial Utilities software.

4.1.5 OTHER OPERATING SYSTEMS

Refer to the appropriate directory on Disk 1 of the Serial Utilities software.

4.2 Installing the Hardware

You can install the Serial Host Adapter in any of the PCI expansion slots. It contains several jumper straps for each port that you must set for proper operation.

1. Power off the PC. Disconnect the power cord.
2. Remove the PC cover.
3. Locate an available PCI slot and remove the blank metal slot cover.
4. Gently insert the Adapter into the slot. Make sure that it is seated properly.
5. Connect the DB78 male connector end of the octopus cable to the DB78 female connector on the card.
6. Replace the screw.
7. Replace the cover.
8. Connect the power cord.

5. Technical Description

5.1 Interrupts

A good analogy of a PC interrupt is a telephone ringing. The phone bell is a request for us to stop what we are currently doing and take up another task (speak to the person on the other end of the line). This is the same process the PC uses to alert the CPU that a task must be performed. The CPU, upon receiving an interrupt, makes a record of what the processor was doing at the time and stores this information on the “stack”; this allows the processor to resume its predefined duties after the interrupt is handled, exactly where it left off. Every main sub-system in the PC has its own interrupt, frequently called an IRQ (short for Interrupt ReQuest).

5.2 Why Use an ISP?

The Interrupt Status Port (ISP) is a read-only 8-bit register that sets a corresponding bit when an interrupt is pending. Port 1 interrupt line corresponds with Bit D0 of the status port, Port 2 with D1, etc. The use of this port means that the software designer now only has to poll a single port to determine if an interrupt is pending.

The ISP is at Base+7 on each port (example: Base=280 hex, Status Port=287, 28F...etc.). The Adapter will allow any one of the available locations to be read to obtain the value in the status register. Both status ports on the Adapter are identical, so either one can be read. Example: This indicates that Channel 2 has an interrupt pending.

Bit Position:	7	6	5	4	3	2	1	0
Value Read:	0	0	0	0	0	0	1	0

6. Connector Pin Assignments

6.1 DB25 (RS-232 DTE)

Signal	Name	Pin #	Mode
GND	Ground	7	
TD	Transmit Data	2	Output
RTS	Request to Send	4	Output
DTR	Data Terminal Ready	20	Output
RD	Receive Data	3	Input
CTS	Clear to Send	5	Input
DSR	Data Set Ready	6	Input
DCD	Data Carrier Detect	8	Input
RI	Ring Indicator	22	Input

6.2 DB78 Connector Pin Assignments

Port #	1	2	3	4	5	6	7	8
TD	36	12	27	3	75	51	66	42
RD	37	11	28	2	76	50	67	41
RTS	17	31	8	22	56	70	47	61
CTS	16	32	7	23	55	71	46	62
DTR	35	13	26	4	74	52	65	43
DSR	18	30	9	21	57	69	48	60
DCD	38	10	29	1	77	49	68	40
RI	15	33	6	24	54	72	45	63
GND	34	14	25	5	73	53	64	44

Appendix A: Troubleshooting

A.1 Using the Serial Utility Diskettes

A Serial Utility diskette comes with the Serial Host Adapter for use in troubleshooting. If you still cannot solve a problem after reading this chapter, call for technical support.

1. Identify all I/O adapters currently installed in your system, including your on-board serial ports, controller cards, sound cards, etc. Identify the I/O addresses used by these adapters, as well as the IRQ (if any).
2. Configure your Serial Host Adapter so that there is no conflict with currently installed adapters. No two adapters can occupy the same I/O address.
3. Make sure the Adapter is using a unique IRQ. While this Adapter does allow the sharing of IRQs, many other adapters (such as SCSI adapters and on-board serial ports) do not. The IRQ is typically selected via an on-board header block. Refer to **Chapter 3** for help in choosing an I/O address and IRQ.
4. Make sure the Adapter is securely installed in a motherboard slot.
5. For Windows 95/98 and Windows NT, the diagnostic tool “WinSSD” is installed in the Adapter folder on the Start Menu during the startup process. First find the ports using the Device Manager, then use “WinSSD” to verify that the ports are working.
6. When running DOS, Windows 3.x or other operating systems, refer to Serial Utilities Disk 1 and this manual to verify that the Adapter is configured correctly. The supplied software contains a diagnostic program “SSD” that runs under DOS and will verify if an adapter is configured properly. This diagnostic program is easy to use. Refer to the README.txt file on the supplied diskette for detailed instructions on using “SSD.”

A.2 Calling for Technical Support

If the procedures described in **Section A.1** do not solve your problem, call Black Box Technical Support at 724-746-5500. Have the following information ready when you call:

1. Current adapter settings. If possible, have the Adapter installed in a computer ready to run diagnostics.
2. This user manual for reference.

Appendix B: RS-232 Electrical Interface

The most widely used communication standard is RS-232. It's been defined and revised several times and is sometimes also called EIA/TIA-232. The IBM AT computer defined the RS-232 port on a DB9 connector, and subsequently the EIA/TIA approved this implementation as the EIA/TIA-574 standard, which is defined as the "9-Position Non-Synchronous Interface between Data Terminal Equipment and Data Circuit-Terminating Equipment Employing Serial Binary Data Interchange."

RS-232 can operate at data rates of up to 20 kbps at distances less than 50 ft. (15.2 m). The absolute maximum data rate may vary depending on line conditions and cable lengths. RS-232 is a single-ended or unbalanced interface, meaning that a single electrical signal is compared to a common signal (ground) to determine binary logical states. The RS-232 and the EIA/TIA-574 specification define two types of interface circuits, Data Terminal Equipment (DTE) and Data Circuit-Terminating Equipment (DCE). The Serial Host Adapter is a DTE device.

Appendix C: Asynchronous Communication

In serial data communication, individual bits of a character are transmitted consecutively to a receiver that assembles the bits back into a character. Data rate, error checking, handshaking, and character framing (start/stop bits) are pre-defined and must correspond at both the transmitting and receiving ends.

Asynchronous communication is the standard means of serial data communication for PC and compatible computers. The original PC was equipped with a communication or COM port that was designed around an 8250 Universal Asynchronous Receiver Transmitter (UART), which allows asynchronous serial data to be transferred through a simple and straightforward programming device. The Serial Host Adapter (IC142C) uses a much newer 16554 UART that also features buffering.

Asynchronous communication works this way: A start bit, followed by a pre-defined number of data bits (5, 6, 7, or 8) defines character boundaries for asynchronous communication. The end of the character is defined by the transmission of a pre-defined number of stop bits (usually 1, 1.5, or 2).




Figure C-1. Asynchronous Communication Bit Diagram.

An extra bit used for error detection is often appended before the stop bits. This special bit is called the parity bit. Parity is a simple way to determine if a data bit has been lost or corrupted during transmission. There are several methods for implementing a parity check to guard against data corruption. Common methods are called [E]ven Parity or [O]dd Parity. Sometimes parity is not used to detect errors on the data stream (this is called [N]o Parity). Because each bit in asynchronous communication is sent consecutively, it is wrapped (framed) by pre-defined bits to mark the beginning and end of the serial transmission of the character. The data rate and communication parameters for asynchronous communication have to be the same at both the transmitting and receiving ends. The communication parameters are baud rate, parity, number of data bits per character, and stop bits—for example, 9600, N, 8, 1.

Appendix D: Board Layout




Figure D-1. Board Layout.

Appendix E: Compliance Notices

E.1 Federal Communications Commission Statement

See page 1.

E.2 EMC Directive Statement



Products bearing the CE Label fulfill the requirements of the EMC directive (89/336/EEC) and of the low-voltage directive (73/23/EEC) issued by the European Commission.

To obey these directives, the following European standards must be met:

- EN55022 Class A - “Limits and methods of measurement of radio interference characteristics of information technology equipment”
- EN50082-1 - “Electromagnetic compatibility - Generic immunity standard” Part 1: Residential, commercial and light industry
- EN60950 (IEC950) - “Safety of information technology equipment, including electrical business equipment”

Always use cabling provided with this product if possible. If no cable is provided or if an alternate cable is required, use high-quality shielded cabling to maintain compliance with FCC/EMC directives.