


## Rear Interface Switch Cards



---

### CUSTOMER SUPPORT INFORMATION

Order **toll-free** in the U.S.: Call **877-877-BBOX** (outside U.S. call **724-746-5500**)

FREE technical support 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**

Mailing address: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018

Web site: [www.blackbox.com](http://www.blackbox.com) • E-mail: [info@blackbox.com](mailto:info@blackbox.com)

## Specifications

**Connectors** — SM720C: (3) DB25 female; SM721C: (3) M/34 female; SM722C: (3) DB15 female; SM723C: (3) RJ-11; SM724C: (3) RJ-45

**Leads Supported** — SM720C: 25; SM721C: 34; SM722C: 15; SM723C: 6; SM724C: 8


**Power** — From the rack chassis

**Size** — ¼-size card

**Weight** — 1 lb. (0.5 kg)

## Description

Rear cards work with front cards to manage lines. The front card contains the switching and patching circuitry; the rear card contains the cable interface circuitry. The front card and the rear card mate when they are inserted into a rack (see the illustration below).



Rear cards and front cards that mate must be compatible.

In a rack, there are 16 slots for front cards, and 16 corresponding slots for rear cards. The cards occupy one slot.

Rear cards have ports that correspond to their applications. They also have a slot number window that

## REAR INTERFACE SWITCH CARDS

indicates the number of the slot in which the card is installed.

Rear cards available include:

<b>Model</b>	<b>Application</b>	<b># of Slots</b>	<b>Connectors</b>
SM720C	A/B switch (and patch)	1	A, B, Common: DB25F
SM721C	A/B switch (and patch)	1	A, B, Common: V.35F
SM722C	A/B switch (and patch)	1	A, B, Common: DB15F
SM723C	A/B switch	1	A, B, Common: RJ-11
SM724C	A/B switch	1	A, B, Common: RJ-45

Each card comes with 2 screws and this users' manual.

# Installation

*To Install a Rear Card:*

1. First, you'll need to insert the corresponding front card and tighten the screws. You don't need to fill all slots in a rack or fill slots in any particular order.
2. Insert the rear card and tighten the screws.

*To Replace a Rear Card:*

1. Unscrew the mounting screws.
2. Slide the card out of the rack and install a replacement.

## CAUTION

Electrostatic Discharge (ESD): Cards are ESD-sensitive. To prevent ESD damage, always wear grounding wrist straps when touching, removing, or inserting cards. Store and transport cards in sealed static-shielding containers.



© Copyright 2002. Black Box Corporation. All rights reserved.

---

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746