

Power Supply Module Installation Guide


PS7412A — PS7412A-DC — PS7412A-2 — PS7412A-2DC — LMC5004AC — LMC5005AC



ATTENTION! This *Power Supply Module* is for use <u>only</u> in modular chassis from Black Box. The manufacturer is not responsible for any loss or damage resulting from misuse of this product.

To install, simply unscrew and remove the blank bracket covering the unused power supply slot, then slide the *Power Supply Module* in until it fits securely in its socket at

the rear of the slot. Secure the module in place by tightening the thumbscrews on the *Power Supply Module* bracket. Attach the power cable and, on AC power supplies, move the toggle switch to the ON position. When the unit is receiving power, the green PWR (power) LED will light.



Black Box Customer Service

Call: (724) 746-5500 Phone orders 24 hours a day, 7:00 AM Monday to midnight Friday; 8:00 AM to 4:00 PM Saturday (EST)

Fax: (724) 746-0746 or in North America 1-800-321-0746

Mail order: Black Box Corporation, 1000 Park Drive, Lawrence, PA

15055-1018

Technical Support and fax orders 24 hours a day.

Warranty

Contact Black Box Corp. for warranty information.

For complete installation, operation and safety information, please refer to the documentation supplied with your chassis or contact Black Box.



1000 Park Drive • Lawrence, PA 15055-1018 USA TEL: (724) 746-5500 • FAX: (724) 873-7049 info@blackbox.com • www.blackbox.com

© 2000 Black Box Corp. All rights reserved.

The information in this document is subject to change without notice. Black Box assumes no responsibility for any errors that may appear in this document. Product names are trademarks of the manufacturer. Other brands or product names may be trademarks and are the property of their respective companies.