




© Copyright 1997. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746



16-Port Type 3 MAU



**CUSTOMER
SUPPORT
INFORMATION**

Order **toll-free** in the U.S. 24 hours, 7 A.M. Monday to midnight Friday: **877-877-BBOX**
FREE technical support, 24 hours a day, 7 days a week: Call **724-746-5500** or fax **724-746-0746**
Mail order: **Black Box Corporation**, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

**FEDERAL COMMUNICATIONS COMMISSION
AND
INDUSTRY CANADA
RADIO FREQUENCY INTERFERENCE STATEMENTS**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart J of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par Industrie Canada.

NORMAS OFICIALES MEXICANAS (NOM) ELECTRICAL SAFETY STATEMENT

INSTRUCCIONES DE SEGURIDAD

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.
4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc..
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico deber ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.

11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.
12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equipo eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.
16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

TRADEMARKS

IBM® and AS/400® are registered trademarks of IBM Corporation.

All applied-for and registered trademarks are the property of their respective owners.

CONTENTS

1. Specifications	.8
1.1 Lobe Port Initialization	.8
1.2 RJ-45 Connectors	.9
1.2.1 Automatic Wrap of Ring In and Ring Out	.11
1.2.2 Lobe Port Initialization	.11
1.3 Cable Specifications	.11
1.3.1 Category 5 Cable	.11
1.3.2 Type 3 Cable	.12
2. Introduction	.14
2.1 Token Ring Background	.14
2.2 MAUs	.17
3. Installation	.18
3.1 Installation Background	.18
3.1.1 Main Ring	.18
3.1.2 Backup Path	.20
3.1.3 Adjusted Ring Length	.23
3.1.4 Lobe Length	.23
3.1.5 Cable Type	.24
3.1.6 Repeaters	.24
3.1.7 Bridges	.24
3.1.8 16-Mbps Token Rings	.24
3.2 Calculating Distances	.25
3.3 Distance Charts	.27
3.4 Completing the Installation	.32
3.4.1 Station Port Initialization	.33
3.4.2 Installation Procedure	.34
4. Problem Determination	.35
5. Glossary	.37

1. Specifications

Power — No external power source is required.

Data Rate — 4 and 16 Mbps. Type 3 cable may be used at 16 Mbps when media filters are used at the workstation or other attaching device.

Cable — See **Section 1.3, Cable Specifications**.

Standard — All models meet the IEEE 802.5 Standard.

Connectors — Female RJ-45. These connectors will accept either RJ-45 or RJ-11 male connectors.

Battery (for operation of port-reset feature) — 3V lithium, Duracell 1/2 AA SE or equivalent. Field-replaceable.

Operating Temperature — 32 to 131°F (0 to 55°C)

Humidity — Up to 95% non-condensing

Size—1.72"H x 17.25"W x 6"D (4.37 x 43.82 x 15.24 cm)

Weight — 23.25 lb. (1.46 kg)

This MAU has female RJ-45 shielded lobe connectors. The connectors labeled Ring In and Ring Out are for attachment to the token ring. The MAU has sixteen station connectors.

The MAU also has one LED for each terminal port. When a terminal-port LED is lit, it indicates that the device attached to that port is connected to the token ring.

1.1 Lobe-Port Initialization

The station ports can be in an incorrect state for station attachment, and if they are, the MAU will be inoperable until the ports are reset. Use the Reset button to reset them.

The Reset button on the front panel is used to align the relays in the station ports so they are ready for operation. This feature is powered by a replaceable battery.

To operate the port-reset feature, press the Reset button. When the LED above the Reset button lights, it indicates that the battery is operable and that all inactive station ports will be aligned. Ports with active stations on them will not be disturbed.

1.2 RJ-45 Connectors

The diagram below shows the transmit and receive pins in the female RJ-45 connectors.




Figure 1-1. RJ-45 connector transmit & receive pins

RJ-11 male connectors may be used instead of RJ-45 male connectors on the twisted-pair cables used in the network. Both types will work in the female connectors on the MAUs. Whether RJ-45 or RJ-11 male connectors are used, the transmit and receive pins are always the four center pins in the connector, as shown in **Figure 1-1**.

IMPORTANT NOTE:

The cable used with your MAUs must have at least two twisted pairs of wire for data, no matter what cable type is used. This means a minimum of four separate wires, whether or not you will use all four. The cable must be wired straight-through, as shown in **Figure 1-2**. Do not connect transmit and receive wires in the same twisted pair of wires.




Figure 1-2. Correct RJ-45 connector and cable wiring.

1.2.1 AUTOMATIC WRAP OF RING IN AND RING OUT

When no connector is inserted into Ring In or Ring Out ports, the port will automatically wrap, or loop back, to utilize the backup path. The backup path is described in **Section 4.1, Installation Background**.

1.2.2 LOBE-PORT INITIALIZATION

The station ports can be in an incorrect state for station attachment, and if they are, the MAU will be inoperable until the ports are reset. Use the reset button to reset them.

The Reset button on the front panel is used to align the relays in all inactive station ports so they are ready for operation. This feature is powered by a replaceable battery.

To operate the port-reset feature, press the Reset button. When the LED above the Reset button lights, it indicates that the battery is operable and that all inactive station ports will be aligned. Ports with active stations on them will not be disturbed.

1.3 Cable Specifications

1.3.1 CATEGORY 5 CABLE

This cable has been defined by the EIA/TIA as the cable of choice for data applications up to 100 Mbps. See EIA/TIA specification #568 A/B for building wiring recommendations.

- UTP and STP available
- 22 and 24 gauge generally available
- Impedance 100 ohms (15% from 512 kHz to 100 MHz)
- Maximum attenuation is 67.0 dB per 1,000 at 100 MHz.

1.3.2 TYPE 3 CABLE

The Type 3 cable used with the MAU should be standard twisted-pair telephone building wire. Recommended wire gauge is 24 or 22 AWG, Belden 9562 or equivalent. The following requirements should be met:

- Solid copper twisted pairs, with at least two twists per foot
- A maximum DC resistance of 28.6 ohms per 1000 feet
- Characteristic impedance:
 - 90 to 120 ohms at 256 kHz
 - 87 to 117.5 ohms at 512 kHz
 - 85 to 114 ohms at 772 kHz
 - 84 to 113 ohms at 1000 kHz
- Maximum attenuation per 1000 feet:
 - 4.00 dB at 256 kHz
 - 5.66 dB at 512 kHz
 - 6.73 dB at 772 kHz
 - 8.00 dB at 1000 kHz

NOTE

Commonly available consumer telephone cable, sometimes called “flat cable” or “silver satin,” should not be used. This type of cable can drastically reduce the cable lengths possible in your network. Exceptions to this are the patch cables used to connect MAUs in the same wiring closet in 4 Mbps networks; they may be made of this type of cable, but they should be no more than three feet in length. In 16-Mbps networks, however, silver satin of any length should not be used.

Electrical Interference

Because Type 3 cable is unshielded, care must be taken to avoid areas of electrical disturbance. Some examples of sources of electrical disturbance are:

- Fluorescent lights
- Power cables
- Electric motors
- Radio transmitters

2. Introduction

This user's guide covers the 16-Port Type 3 MAU, which has 16 RJ-45 connectors.

2.1 Token Ring Background

Computer users have become less and less dependent on large centralized computing systems because of continuing increases in the processing power of microcomputers and minicomputers. Interconnecting micros, minis and mainframes into Local Area Networks (LANs) for the purpose of resource sharing and peer-to-peer communications can improve user productivity within office environments.

The IBM® Token-Ring Network is a network system that allows interconnection of PCs and their associated devices, in addition to allowing interconnection of PCs to minicomputers and mainframes.

The IBM Token-Ring Network conforms to the IEEE 802.5 Token Ring Access Method standard. Other token ring networks conform to this standard as well.

The topology of the IBM Token-Ring Network is known as a “star-wired ring.” The devices on the ring are attached to a single, unidirectional loop, and the loop is wired in a physical star. See **Figure 2-1**.




Figure 2-1. Star-wired topology

Each device on the ring is known as an attaching device. Each attaching device is connected to a wiring concentrator, or multistation access unit (MAU). The cable between the MAU and the attaching device is known as a lobe.

The purpose of a MAU is to isolate its attaching devices from the main data path of the ring. In this way, a problem occurring on the device side of the MAU will not usually affect the operation of the entire ring. Also, concentrating station connections in a small area aids troubleshooting. A PC interfaces the network through the use of a token-ring adapter, which is a card installed in the PC. When the adapter receives the token and has no data to transmit, it electrically regenerates the token and sends it to the next device on the line.

The term “token” comes from the access scheme of the network. A unique bit sequence, or token, is continuously passed from device to device in sequence. Only one token is on a ring at one time. When a device needs access to the network, it must wait until it receives the token. The device will then append to the token the data it wishes to transmit, and the token becomes a frame. After the frame is transmitted to its destination, it returns to the original sender, which confirms that it was received. The sending station then releases a free token. (In a 16-Mbps ring, the sequence can be slightly different from what is given here, but the basic concepts are the same.) The first token is made by the first device turned on in the network.

To gain access to the network, the adapter in an attaching device presents a small current to the MAU. When the MAU senses this current, a relay is opened and the attaching device is connected to the ring.

The network consists of the adapters, the MAUs and the cabling that connects them.

One or more of the devices (for example, a powerful PC or an AS/400®) are typically designated as file servers; other workstations can then access or download files from the servers. The token ring can use communications software such as E-mail to facilitate communications among workstations on the ring.

Using IBM Cabling System Type 3 cable (unshielded twisted pair), up to 72 attaching devices (printers, processors, controllers) may be attached to a single ring.

Using Type 1 or Type 2 cable, up to 260 attaching devices may be attached to a single ring.

With Type 3 cabling, up to eight MAUs may be used in a single ring. With Types 1 or 2 cable, up to 33 MAUs may be used.

Many more devices may be interconnected using source-routing token-ring bridges (between rings) and gateways (between token-ring and non-token-ring communications environments, such as the IBM 5250 system).

2.2 MAUs

Features

- Full compatibility with the IBM Token-Ring Network.
- Inexpensive Type 3 cable may be used in addition to Types 1 and 2 cable. You may also use UTP or STP 100-ohm Category 5 cable.
- RJ-45 connectors.
- Diagnostic LEDs.
- Terminal (lobe) ports on MAU are initialized with a front-panel pushbutton, eliminating the need for a separate port setup tool.

3. Installation

3.1 Installation Background

This section gives general information on planning the network using MAUs, and later sections will cover the installation of the MAU.

Before installing your MAUs and attaching devices, it is very important that the network be carefully planned. The most important factors for the physical part of the network are:

- Main ring length and distance between MAUs
- Length of the lobes attaching MAUs to devices
- Number of wiring closets
- Verifying that the proper type of cable is used (see **Section 1.3, Cable Specifications**)
- Safeguarding against electrical interference, especially when Type 3 cable is used.

A copy of the floor plans of the buildings that will use the token-ring network will help greatly in planning the installation.

NOTE

When using Type 3 cable with 4-Mbps token rings, Black Box® Media Filters (part number LT057) must be used to take full advantage of the lobe lengths stated in this chapter. When using Type 3 cable at 16Mb, Media Filters must be used. Using another brand of media filter may result in decreased lobe length.

3.1.1 MAIN RING

When multiple MAUs are used in a token-ring network, the main ring consists of the cable between the MAUs. The length of the main ring is critical to proper network operation. The main ring does not include the cable from MAUs to their attaching devices (these cables are called lobes).




Figure 3-1. Main Ring.

If there is only one MAU for the entire ring, the main ring can be considered to have no length for installation purposes.

3.1.2 BACKUP PATH

In a normal configuration, there is an unused pair of wires in the twisted-pair cable used in the network. This extra pair of wires, used with a backup circuit inside the MAUs, is called the backup path.




Figure 3-2. Backup path.

The backup path is designed to enable the network to continue to operate while a problem such as a faulty cable or MAU is being repaired.

For example, if a breakdown occurs in the cable between MAU 1 and MAU 2 as in Figure 9, the rest of the ring will remain in operation if the backup path is used. Note that when the backup path is used, it becomes part of the main ring and its length must be included in the main ring length. In most situations, the network should be designed to allow the backup path to be used. The backup path is automatically used by the MAU when no connector is inserted in Ring In or Ring Out ports.

The length of the main ring is critical to the proper operation of the token-ring network. If the network is designed without taking the length of the backup path into consideration, the backup path may not be usable if it is needed. It may force the signal to be transmitted so far that attenuation makes it unreadable.

When the network is first activated at the start of a business day, it may consist of only one active attaching device connected to the main ring. For this example, assume that the attaching device is on the longest lobe.




Figure 3-3. Main ring and first device. The backup path is not in use.

16-PORT TYPE 3 MAU

The signal generated by the attaching device must travel up its lobe to the main ring, around the entire main ring, and back down the lobe to the device without being regenerated. If the backup path were being used with the shortest section of cable removed, the path would be much longer. Usually, the longest possible transmission path occurs when the backup path is being used with the shortest section of cable removed, and when the station on the longest lobe is the only active station on the network. The longest possible distance must be assumed when planning the network.




Figure 3-4. Transmission distance using the backup path.

3.1.3 ADJUSTED RING LENGTH

In networks that use more than one MAU, adjusted ring length (ARL) is the total length of the cable connecting MAUs (the main ring) minus the shortest inter-MAU cable. Patch cables less than three feet in length are not included in this calculation. See the diagram below.




Figure 3-5. Adjusted ring length.

The use of ARL is intended to simplify network planning. The length of the longest lobe in the network is added to ARL, and the sum is compared to a chart later in this chapter to determine maximum ring size. See **Section 3.2, Calculating Distances**.

3.1.4 LOBE LENGTH

The distance between each attaching device and its MAU is very important in network planning. Maximum lobe lengths are a function of several factors, and they will vary depending on how the network is configured. See **Section 3.2, Calculating Distances**.

3.1.5 CABLE TYPE

Type 1, Type 2, Type 3, or Category 5 cabling may be used with the MAU. Usually, Type 3 or Category 5 100-ohm cable is used with RJ-45-equipped MAUs, and Types 1 or 2 cable are used with data connector-equipped (DC) MAUs.

The MAU can be used in either 4-Mbps or 16-Mbps token rings. Maximum distances will be less in 16-Mbps rings.

3.1.6 REPEATERS

Repeaters can vastly increase the geographic distance of a 4- or 16-Mbps network. If there is more than one wiring closet in the ring, repeaters are recommended between each wiring closet. If they are used, the length of the main ring can often be disregarded, and maximum lobe lengths can be achieved. Copper-wire repeaters can transmit the network signal up to 1200 feet (365 m) on Type 3 cable and up to 2400 feet (731 m) on Types 1 or 2 cable. Fiberoptic repeaters can transmit the network signal up to 10,000 feet (3 km) on fiberoptic cable.

If repeaters will be used, it will affect the installation of MAUs. Follow the installation instructions given in the manuals for your repeaters.

3.1.7 BRIDGES

Bridges can help organize the rings of a network and enhance performance from the viewpoint of network users.

Token Ring Bridges are available in local and remote versions, and they provide the capability to extend your network around the world. They also provide increased network control and management functions, based on their complete IBM compatibility.

3.1.8 16-MBPS TOKEN RINGS

The MAU can be used in 16 Mb token rings on Types 1, 2, 3, or Category 5 cabling. Category 5 cable is generally preferred for this application because of its ability to support data rates up to 100 Mbps. This provides some margin for future upgrades.

3.2 Calculating Distances

A simplified distance calculation method based on maximum cable length follows:

The sum of the ARL (adjusted ring length, defined in Section 3.1, Installation Background, and in the Glossary) plus the cable length of the longest lobe in the ring must be less than or equal to the distance given for your network's configuration in one of the tables in Figures 14 through 19. Expressed as a formula, this is:

ARL + longest lobe (maximum distance for your configuration (from the appropriate table)

NOTE

The distances given in the tables for Type 3 cable will require Black Box media filters (part number LT057) between the adapters and the network cable. Using another brand of media filter may result in decreased lobe length.

16-PORT TYPE 3 MAU

EXAMPLE

This example illustrates a proper network plan using MAUs. All cable distances given assume that 24 gauge Type 3 cable is used in the network




Figure 3-6. Example.

Assume that a network is desired which has devices located on three floors of a building, and four MAUs will be used. Using the cable lengths shown in Figure 13, the total length of the main ring is 125 feet ($35 + 30 + 60$). The patch cable connecting MAUs 2 and 3 has been ignored. Its length is insignificant, and it is assumed that if it goes bad it will be replaced instead of looping the ring onto the backup path. The ARL is 95 feet (total main ring length minus the shortest segment: $125 - 30$).

The maximum distance for this network is 435 feet, as taken from the chart in **Table 3-1** (24-gauge Type 3 cable, four MAUs and three wiring closets). This means that the maximum lobe length allowed on this network is 340 feet ($435 - 95$). Each lobe on this network can be up to 340 feet in length.

Completing the Installation

Once the network has been thoroughly planned and all wiring has been routed to the work areas where network devices will be located, follow the procedure given in **Section 3.4, Completing the Installation**.

3.3 Distance Charts

The charts on the following pages are used with the distance formula given in **Section 3.2, Calculating Distances**.

Table 3-1. 4-Mbps Distance Chart for Type 3 Cable. Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
19 Gauge					
1	600 (183)				
2	585 (181)	575 (175)			
3	570 (174)	560 (171)	550 (168)		
4	555 (169)	545 (166)	535 (163)	525 (160)	
5	540 (165)	530 (162)	520 (158)	510 (155)	500 (152)
6	525 (160)	515 (157)	505 (154)	495 (151)	485 (148)
7	510 (155)	500 (152)	490 (149)	480 (146)	470 (143)
8	495 (151)	485 (148)	475 (145)	465 (142)	455 (139)

16-PORT TYPE 3 MAU

Table 3-1. 4-Mbps Distance Chart for Type 3 Cable (continued).
Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
22 Gauge					
1	550 (168)				
2	535 (163)	525 (160)			
3	520 (158)	510 (155)	500 (152)		
4	505 (154)	495 (151)	485 (148)	475 (145)	
5	490 (149)	480 (146)	470 (143)	460 (140)	450 (137)
6	475 (145)	465 (142)	455 (139)	445 (136)	435 (133)
7	460 (140)	450 (137)	440 (134)	430 (131)	420 (128)
8	445 (136)	435 (133)	425 (130)	415 (126)	405 (123)
24 Gauge					
1	500 (152)				
2	485 (148)	475 (145)			
3	470 (143)	460 (140)	450 (137)		
4	455 (139)	445 (136)	435 (133)	425 (130)	
5	440 (134)	430 (131)	420 (128)	410 (125)	400 (122)

Table 3-1. 4-Mbps Distance Chart for Type 3 Cable (continued).
Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
6	425 (130)	415 (126)	405 (123)	395 (121)	385 (117)
7	410 (125)	400 (122)	390 (119)	380 (116)	370 (113)
8	395 (120)	385 (117)	375 (114)	365 (111)	355 (108)
26 Gauge					
1	470 (143)				
2	455 (139)	445 (136)			
3	440 (134)	430 (131)	420 (128)		
4	425 (130)	415 (126)	405 (123)	395 (121)	
5	410 (125)	400 (122)	390 (119)	380 (116)	370 (113)
6	395 (120)	385 (117)	375 (114)	365 (111)	355 (108)
7	380 (116)	370 (113)	360 (110)	350 (107)	340 (104)
8	365 (111)	355 (108)	345 (105)	335 (102)	325 (99)

16-PORT TYPE 3 MAU

Table 3-2. 16-Mbps Distance Chart for Type 3 Cable. Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
19 Gauge					
1	221 (67)				
2	215 (66)	212 (65)			
3	210 (64)	207 (63)	204 (62)		
4	205 (62)	202 (62)	199 (61)	196 (60)	
5	200 (61)	197 (60)	194 (59)	191 (58)	188 (57)
6	195 (59)	192 (59)	189 (58)	186 (57)	183 (56)
7	190 (58)	187 (57)	184 (56)	181 (55)	178 (54)
8	184 (56)	182 (55)	179 (55)	176 (54)	173 (53)
22 Gauge					
1	215 (66)				
2	210 (64)	207 (63)			
3	205 (62)	202 (62)	200 (61)		
4	200 (61)	197 (59)	195 (59)	191 (58)	
5	195 (59)	192 (59)	189 (58)	187 (57)	183 (56)

Table 3-2. 16-Mbps Distance Chart for Type 3 Cable (continued).
Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
6	190 (58)	187 (57)	184 (56)	182 (55)	179 (55)
7	184 (56)	182 (55)	180 (55)	176 (54)	174 (53)
8	180 (55)	177 (54)	174 (53)	172 (52)	169 (52)
24 Gauge					
1	210 (64)				
2	205 (62)	202 (62)			
3	200 (61)	197 (60)	195 (59)		
4	195 (59)	193 (59)	189 (58)	187 (57)	
5	190 (58)	188 (57)	184 (56)	182 (55)	179 (55)
6	186 (56)	183 (55)	180 (55)	176 (54)	174 (53)
7	181 (55)	178 (54)	174 (53)	172 (52)	169 (52)
8	176 (54)	173 (53)	170 (52)	167 (51)	165 (50)
26 Gauge					
1	189 (58)				
2	184 (56)	182 (55)			

16-PORT TYPE 3 MAU

Table 3-2. 16-Mbps Distance Chart for Type 3 Cable (continued).
Distances are given in feet (meters).

Number of MAUs	Number of Wiring Closets				
	1	2	3	4	5
3	180 (55)	178 (54)	175 (53)		
4	176 (54)	173 (53)	171 (52)	168 (51)	
5	172 (52)	169 (52)	166 (51)	164 (50)	161 (49)
6	167 (51)	165 (50)	162 (49)	160 (49)	157 (48)
7	162 (49)	160 (49)	158 (48)	155 (47)	153 (47)
8	158 (48)	156 (48)	153 (47)	151 (46)	148 (45)

3.4 Completing the Installation

3.4.1 STATION-PORT INITIALIZATION

The station ports can be in an incorrect state for station attachment, and if they are, the MAU will be inoperable until the ports are reset. Use the reset button to reset them.

The Reset button on the front panel is used to align the relays in the station ports so they are ready for operation. This feature is powered by a replaceable battery.

To operate the port reset feature, press the Reset button. When the LED above to the Reset button lights, it indicates that the battery is operable and that all inactive station ports will be aligned. Ports with active stations on them will not be disturbed.

3.4.2 INSTALLATION PROCEDURE

Once the network has been thoroughly planned and all wiring has been routed to the work areas where network devices will be located, use this procedure to finish the installation.

1. If RJ-45-equipped MAUs are used, attach media filters to the network ports on the adapter cards in the attaching devices (unless the adapters are equipped with media filters). Plug the network cable into the appropriate connector in the media filters. For 16-Mbps applications on Type 3 cabling, use media filters.
2. Plug all terminal cables into the appropriate terminal connectors on the MAUs.

NOTE

Make sure that thorough documentation is kept on all network devices, their locations, their sequence on the ring, and their associated MAU ports.

3. If the ring is not running, connect the MAUs to the main ring using the Ring In and Ring Out connectors. (Ring In receives the cable from the previous MAU; Ring Out connects to the cable going to the next MAU.) Bring up the ring and make sure that the attaching devices are powered on and are set up to request network access.

If the ring is already operating, the new MAUs may be installed by attaching Ring In and Ring Out cables to the appropriate MAU connectors, as long as the ring is not broken for more than five to ten seconds.

CAUTION

If the main ring is broken for more than five to ten seconds, the ring will be completely disabled and will have to be reinitialized. Data loss may occur.

4. All terminal port LEDs should light if the ports have devices attached and if the devices are powered on and are set up to request network access.

If the MAU does not seem to be operating properly, see **Chapter 4, Problem Determination**.

4. Problem Determination

MAUs are designed for ease of use. By using the following guide, most problems can be quickly isolated and corrected.

Procedure

If an attaching device is validly connected to the network, the terminal port LED on the MAU will be on, and the attaching device should be able to communicate properly on the network.

If the attaching device does not operate properly, first check to see that the device is powered on and is set up to request network access.

Next, check to see if the terminal port LED on the MAU is on. If it is on, the problem is likely to be one of the following:

- The token-ring adapter card in the attaching device is not operating properly.
- The software in the token-ring adapter card is not set up correctly.
- There is a problem in the network itself. If this is the case, there will probably be trouble elsewhere in the network.
- The building wiring has improper connections.

If the terminal LED is not on, verify that the lobe is not too long. Proper lobe lengths are covered in **Chapter 3, Installation**.

If the lobe cable is the proper length, verify that its condition is good, and that it is properly connected at both ends. Also verify that the cable transmits straight through and does not “cross over.” See **Section 1.2, RJ-45 Connectors**, for diagrams of straight-through cabling.

If the lobe cable is all right, the terminal port on the MAU can be tested by connecting the lobe to a terminal port that is known to be good.

If these things are found to be correct, check the cable lengths and cable conditions in the main ring.

If you need help other than what has been provided in this User’s Guide, call for technical support.

5. Glossary

adapter—the card installed in a PC that allows the PC to access the token-ring network.

ARL—adjusted ring length. This is the total length of the cable connecting MAUs in a single token ring, minus the shortest inter-MAU segment.

attaching device—each device directly connected to the token ring. Examples: a PC, a midrange computer such as an IBM AS/400, and a front-end processor for a mainframe computer.

backup path—in a normal configuration, there is an unused pair of wires in the twisted-pair cable used in the network. This extra pair of wires, used in conjunction with a backup circuit inside the MAUs, is called the backup path. It can be used to provide an alternate path if part of the ring is inoperative. See **Section 3.1.2**.

category 5—cable defined by the EIA/TIA for data applications up to 100 Mbps. See **Section 1.3.1**.

frame—when an attaching device appends data to the network token, the token becomes a frame.

lobe—the cable between an MAU and an attaching device.

loopback cable—used with RJ-45-equipped MAUs when there is only one MAU for a ring. It connects ring in to ring out.

main ring—the cable between the MAUs in a ring.

MAU—Multistation Access Unit. This is the wiring concentrator in a token-ring network.

station—synonym for attaching device.

terminating plug—this is used in either the Ring In or Ring Out connector on the MAU to use the backup path. Also called a wrap plug.

token—a unique bit sequence that is passed from station to station in sequence on a token-ring network. Any device wanting access to the network will append data to the token, making it a frame.

token ring—a local area network (LAN) that uses the IEEE 802.5 Token Ring Access Method.

type 1—the IBM Cabling System term for shielded twisted-pair cabling. See **Section 1.3, Cable Specifications**.

type 2—same as type 1, except that the cable includes several pairs of ordinary telephone wire enclosed in the same outer sheath as the shielded data cable. See **Section 1.3, Cable Specifications**.

type 3—the IBM Cabling System term for unshielded telephone twisted-pair wire. See **Section 1.3, Cable Specifications**.